

CVC502-A


HVAC CAN Vehicle Controller

2011 Ford F250-550 - 6.2L, 6.7L, and 6.8L Engines

Contact InterMotive for additional vehicle applications

Diagnostic LEDs can be enabled by momentarily grounding the silver "TEST" ring.

The on-board LEDs will begin flashing as described below. Exit this mode by grounding the TEST ring again.



TEST Ring

STATUS: 2 Digit Diagnostic Code

LED10: controlling front AC clutch

LED9: N/A

LED8: aux fan output active

LED7: Frt AC Req Off input true (J6 p1)

LED6: N/A

LED5: N/A

LED4: active high Rear AC Req is true (J5 p1)

LED3: active low Rear AC Req is true (J6 p3)

LED2: Internal use

LED1: Internal use