


## Installing the Intermotive UIM4 GUI


1. Download the UIM 64 bit GUI
2. Go to your downloads folder and find the UIM4 zip folder, as seen in Figure 1

Figure 1: The downloads folder



3. Right click the UIM4 zip folder and select the 'Extract Here' option (alternatively, one can click 'Extract Files' if one desires to extract elsewhere). Figure 2 shows what the step should look like.

Figure 2: Choose the 'Extract Here' option when the zip folder is right clicked



4. When the folder is extracted a folder called 'UIM4\_v1.4\_64' will be created, double click on the folder. Figure 3 shows the new folder and figure 4 shows the contents of the folder.

Figure 3: The newly created folder

Name	Date modified	Type
Adafruit_VS1053	9/8/2017 9:43 AM	File folder
miscellaneous	11/10/2017 8:48 AM	File folder
MP3Shield Library Demo	5/25/2013 2:32 PM	File folder
old	6/16/2017 4:56 PM	File folder
standalone-vs1053-119b	8/15/2017 3:55 PM	File folder
<b>UIM4_v1.4_64</b>	11/6/2017 11:27 AM	File folder
vs1053an_playrec	8/17/2017 10:18 AM	File folder
vs1053b-patches240	8/15/2017 10:23 AM	File folder
vs1053-standalone-vside-130	7/11/2017 3:54 PM	File folder
UIM4_v1.4_64.zip	11/10/2017 8:45 AM	WinRAR ZIP archive
UIM401 Programming Utility GUI 64bit 072517.zip	11/7/2017 11:23 AM	WinRAR ZIP archive

Figure 4: The inside of new folder


Name	Date modified	Type
ChassisVersionControl.cfg	11/6/2017 8:57 AM	Text Document
rxSerial.dll	7/30/2013 2:15 PM	Application extens...
UIM2.cfg	11/6/2017 8:40 AM	Text Document
<b>UIM4.exe</b>	11/6/2017 11:21 AM	Application

5. Double click on UIM4 file with the UIM icon. A splash screen should be visible for a few seconds and the GUI should come up. Figure 5 shows the splash screen while Figure 6 shows the main GUI page.

Figure 5: GUI Splash Screen




Figure 6: The main GUI page



**\*NOTE\*:** If the main GUI page does not come up, check to see if you are running a 32-bit operating system. If you are using a 32-bit operating system download the other zip folder and repeat steps 2-5. One can check their operating system by going to their start menu, right clicking on computer, and click on properties.

Figure 7



The Operating System can be seen under 'Installed memory (RAM)' and above 'Pen and Touch', Figure 8 shows the system information

Figure 8

