# **Emergency Door Module**

## **Ensures Door Safety & Operation**





- Prevents the vehicle from being started unless the emergency exit door or window is closed and unlocked
- Inexpensive safety enhancement solution for state requirements

#### Features

- Provides an audible alert to warn the driver if the emergency door is open and the engine is running
- Works in conjunction with electronics already in the vehicle
- Includes Intermittent Fault Filter<sup>™</sup> (IFF) technology to eliminate false readings





### **Specifications**

#### **EXAMPLE SCHEMATIC**



SPECIFICATIONS	
Number of Inputs	Five inputs (ajar switch, lock switch, ignition switch,
	power and ground)
Number of Outputs	One output
Current Draw	85 mA
Quiescent Draw	3 mA (sleep current)
Temperature Range	-40°C to 80°C
Dimensions	7.5" L x 4.5" W x 1" H



775-831-2002 | www.InterMotive.net