

FlexSpeak

INTERMOTIVE
VEHICLE
CONTROLS

An ISO 9001:2015 Registered Company

FlexSpeak™

Voice Annunciator System

Overview

- Automated system for configurable audio messages
- Utilizes vehicle CAN data to trigger messages based on inputs when integrated with the InterMotive FlexTech™ control system
- Available in multiple languages
- Simple plug and play connections

Features

- Configurable setup through the module for driver-focused messages
- Connect to the vehicle's public address (PA) speaker system to allow for passenger or external announcements
- Choose from a list of standard messages or record custom messages
- FlexTech™ integration provides a broad range of vehicle data for message triggers including speed, doors, lights, brakes, locks and more
- Offers the flexibility of eight discrete input triggers for non-FlexTech™ applications



Product features may vary by make, model or year. See instructions for complete details.

Proudly distributed by

LGS GROUP
AUTOMOTIVE TECHNOLOGIES

(775) 831-2002

Examples

Driver Alert Messages:

- “Warning: Excessive speed”
- “Warning: Low fuel”
- “Warning: Engine is overheating”
- “Warning: Park brake on”
- “Wheelchair door open”
- “Rear door open”
- “Entry door open”

Passenger Announcement Messages:

- “Welcome to [company name]”
- “Stop requested”
- “Caution: Vehicle is stopping”
- “Caution: Doors are opening”
- “Caution: Vehicle is preparing to move”
- “Watch your step”
- “Please sit down”

Emergency Response Messages:

- “Stand back from the vehicle”
- “K9 officer about to be released”

Work Truck Messages:

- “Caution: Bucket in use”
- “Caution: Construction zone”

