



**IdleLock**<sup>™</sup>

with AutoSense<sup>™</sup> Technology Automatic Secured Idling



- This theft prevention system is <u>automatically</u> activated when the driver exits the vehicle with an InterMotive or OEM fob\*
- Transmission is locked in Park while the engine idles, providing power to equipment
- Key is locked in the ignition cylinder for added security\*
- System is automatically disabled when the driver re-enters the vehicle with the fob



- All lights, equipment and HVAC are still fully functional while the system is engaged
- An output is also provided to allow for disabling auxiliary equipment or to lock
  10 seconds after the fob leaves the vehicle
- If an attempt is made to move the vehicle without the fob detected, the horn will sound\*


POLICE

\*Features may vary by make, model or year. See instructions for complete details. FCA vehicles may require an FCA remote start antenna.



(775) 831-2002





SPECIFICATIONS	
Number of Inputs	Three active inputs (one high, two low)
Number of Outputs	Three active outputs (two high, one low)
Current Draw	120 mA
Quiescent Draw	< 2 mA (sleep current)
Temperature Range	-40°C to 80°C
Dimensions	3" L x 2" W x 1" H

## www.InterMotive.net

REV\_AG U.S. Patent #10,870,411