

Starter Disable

INTERMOTIVE
VEHICLE
CONTROLS

An ISO 9001:2015 Registered Company

Starter Disable

Prevents Engine Start-up in Unsafe Conditions

Overview

- Prevents the vehicle's engine from starting if certain customizable safety conditions are not met
- Unsafe condition examples include: emergency exit locked or open, vehicle not in Park or passenger/roll-up door open
- Inexpensive security enhancement for state or safety requirements

Features

- Provides an audible alert when the disable function has been activated
- Includes a switch input for custom setup
- Works in conjunction with electronics already in the vehicle
- Simple plug and play connections; easy to install with no cutting of factory wires

Product features may vary by make, model or year. See instructions for complete details.



Proudly distributed by

LGS GROUP
AUTOMOTIVE TECHNOLOGIES

(775) 831-2002

REV_AA