



EcoStar Work Truck Version Spec Sheet

- 1 Primary Battery Settings (12V)**
- Primary Battery Restart Voltage _____ Volts **(Default 11.8V)**
(Max 14.5V)
- Low Voltage Restart Delay _____ Seconds **(Default 5 Sec)**
(1 to 1800 seconds)
- Recovery Voltage _____ Volts **(Default 13.50V)**
(Max 14.5V)
- Recharge Timer _____ Seconds **(Default 60 sec)**
(1 to 1800 seconds)

- 2 OPTIONAL Secondary Battery Settings (12-48V)**
- Secondary Battery Restart Voltage _____ Volts **(Default- Disabled)**
(Max 62.0V)
- Low Voltage Restart Delay _____ Seconds **(Default- Disabled)**
(1 to 1800 seconds)
- Recovery Voltage _____ Volts **(Default- Disabled)**
(Max 62.0V)
- Recharge Timer _____ Seconds **(Default- Disabled)**
(1 to 1800 seconds)

- 3 Shutoff Timer**
- Idle Shutoff Time _____ Seconds **(Default 15 Sec)**
(1 to 1800 seconds)

- 4 Enable/ Disable Idle Shutoff Timer (Circle One)**
- Enabled *OR* Disabled (Default- Enabled)

- 5 Minimum & Maximum Outside Ambient Air Operating Temperature**
- Minimum Temperature _____ **F or C (Default -200°F)**
(-200°F to 65°F)
- Maximum Temperature _____ **F or C (Default 200°F)**
(80°F to 200°F)

- 6 Minimum Engine Temperature for Auto-Shutoff**
- Minimum Temperature _____ **F or C (Default -200°F)**
(-200°F to 200°F)

- 7 Brake Pedal Configuration (Select One)**
- 1 Pedal will inhibit the engine off request (This is the default setting- #1)
- 2 Pedal will auto-restart the engine
- 3 Pedal will auto-restart the engine & inhibit the engine off request
- 4 No additional functions (all options still reset the idle timer)

- 8 OPTIONAL Thermistor Add-On Feature (Default setting is disabled)**
(You must order the separate thermistor part to have this option)

- | | | | | |
|--------------|-------|---------------|--|---|
| Low Restart | _____ | F or C | (Default 55°F)
<small>(Range -30°F to 105°F)</small> | Vehicle will restart at this temp & run until the warmup temp has been reached before allowing the vehicle to shutdown |
| Warmup | _____ | F or C | (Default 70°F)
<small>Between low & high restart temps</small> | |
| High Restart | _____ | F or C | (Default 95°F)
<small>(Range -25°F to 110°F)</small> | Vehicle will restart at this temp & run until the cooldown temp has been reached before allowing the system to shutdown |
| Cool Down | _____ | F or C | (Default 80°F)
<small>Between low & high restart temps</small> | |

Please fill out completely	
Installer Company Name	
Installer Contact Name	
Contact Phone Number	
Job Name/ Fleet Name	
Date	
Vehicle	Model
	Year
	Engine

INTERNAL USE ONLY	
Conf. Name:	
Date Created:	